

Zusatz-Hinweis zur Anleitung Ansmann Regler

Rückwärtsgang mode

Der ESC hat 2 Rückwärts-Modi: „An“ und „Aus“.

„An“ Mode: Vollbremsung bis das Modell steht, dann Rückwärtsgang

„Off“ Mode: Schaltet die Rückwärtsfahrt komplett aus und hat nur die Bremsfunktion.

Um zwischen „An“ und „Aus“ zu wechseln, muss folgendes gemacht werden: ESC in die neutral Position, Set up Knopf drücken und gedrückt halten. Rote LED geht an und aus.

Wenn der Rückwärtsgang eingeschaltet sein soll, dann den Set up Knopf loslassen, wenn die rote LED beim Blinken aus ist.

Wenn der Rückwärtsgang deaktiviert sein soll, dann den Set up Knopf loslassen, wenn die rote LED beim Blinken an ist.

Hinsheet for manual Ansmann Speedcontroller

Reverse mode selection

The ESC has 2 reverse modes, 'on' and 'off'.

On mode gives full brakes until the model has stopped then engages reverse.

Off mode removes the reverse function completely allowing the ESC to operate as a forwards and brake only ESC.

To switch between 'on mode' and at any time, when the ESC is in the neutral position, press and hold the set button. The red LED will cycle between on and off, to use the ESC in reversing mode, release the set button when the red LED is off. To use the ESC in brake only mode, release the set button when the red LED is lit. The ESC is ready to use.